

# HS-2D HANDHELD READER

## CONFIGURATION GUIDE




### Hardware Required


Item	Description	Part Number
1	HS-2D Handheld Reader	98-000107-01
2	USB Cable	included
3	Kit, RS-232 Interface, 8 ft. Coiled Cable, USA Power Supply	98-000074-04
	Kit, RS-232 Interface, 8 ft. Coiled Cable, Europe Power Supply	98-000074-05
	Kit, RS-232 Interface, 8 ft. Coiled Cable, UK Power Supply	98-000074-06

### Configuration

#### USB



#### RS-232



### Accessories

Documentation		
RS-232 Interface Kit (USA)	98-000074-04	8 ft. Coiled Cable, USA Power Supply
RS-232 Interface Kit (Europe)	98-000074-05	8 ft. Coiled Cable, Europe Power Supply
RS-232 Interface Kit (UK)	98-000074-06	8 ft. Coiled Cable, UK Power Supply
Microscan Tools CD	37-000001	Software, User's Manuals, Quick Start Guides, Configuration Guides, links to Microscan website